

QUICK START GUIDE

(Keep this for future reference)



Quick Start Guide

Before Use

When using for the first time, remove wraps and follow the steps below:

Recommend to use filtered/distilled water for your health and avoid the formation of limescale.

- Remove the blue sponge from the base of machine.
- Tear away the tape at the bottom of the tank and press the filter lid firmly.
- Fill the water tank with water. Do not add water into the mist outlet or it will cause water leakage.
- Avoid adding essential oil directly to the water, otherwise it may damage the product and cause water leakage. The essential oil should be added to the essential oil tray.

Trouble Shooting

Problem	Possible cause	Solution
Stop working after a period of use and the red light flashes.	The filter(located at the bottom of the water tank)hasn't been cleaned for a long time,causing limescale to clog the filter.	Take out the filter and turn it on again. Tips:Please clean the filter once a week.Rinse it or soak it in vinegar,wipe away the limescale on it.
Stop working during normal use.	It is in Auto Humidistat Mode,and the environmental humidity is higher than the set value.	Wait until the environmental humidity is lower than the set value, it will operate automatically again,or switch to Manual Mode.
Water is leaking from the machine.	Adding essential oils directly to water leads to product damage and water leakage.	Please add essential oil to the essential oil tray. Contact us if leakage is severe.
	The sponge hasn't been removed,or something is stuck in the float inside the base.	Remove the sponge or something else that stuck in the float.
	Dirt is stuck in the drain valve of the water tank.	Refer to cleaning guide.Clean the dirt around the drain valve to ensure the valve can close properly.
	Accidentally pour water into the mist outlet when adding water.	Avoid adding water into the mist outlet.
Leaves white residue or white dust.	Tried above ways and leakage problem still cannot solve.	Contact us for a resend or refund.
	The white residue comes from minerals in the water.	Use distilled water or purchase additional demineralization cartridge for humidifier.

Cleaning Guide

⚠ CAUTION: Always turn off and UNPLUG the humidifier before any cleaning or maintenance.

Cleaning of Water Tank & Drain Valve

- Rinse the tank, remove the dirt inside it with a lint-free cloth. (If there is a significant amount of limescale, it's better soak it in vinegar for about 10 mins)
- To prevent the tank from getting clogged and causing malfunction, take out the filter (located at the bottom of the tank), rinse it and wipe away limescale on it.

- Add water(vinegar) to the tank, rub away limescale/dirt around the drain valve by pressing or rotating the silicone valve.
- Find the water valve below the tank bottom, and press its gray stem 10+ times to release the inside dirt or limescale.

Cleaning of the Base and Atomizer

- Add a splash of vinegar to the base, soak for 10 minutes, then wipe away limescale or dirt with a soft cloth. Fill the base with water, pour it out, and repeat 2 to 3 times. (Avoid rinsing it under the faucet directly)

- Be careful not to spill water into the air outlet on the base to prevent any damage to the machine.

Important Notes

- (1) Clean the water tank and valve every 3 days (72h) of use to ensure a good water quality!
- (2) Use vinegar instead of bleach for soaking cleaning.
- (3) Do NOT use anything hard (eg. steel brush) to clean the silicone valve that might cause damage/leak.

CONTROL AND FUNCTION

Power Button
Turn the humidifier on/off.

Mist Adjust(Manual Mode)
Manually adjust the mist output level.

Humidistat Mode(Auto Mode)
In AUTO mode, the humidifier adjusts mist output automatically based on air humidity.

Light Switch
Turn on/off or adjust the ambient lighting.

Sleep Mode
Switch to sleep mode to reduce any effect of light and noise.

Timer Setting
24-hours timer setting.